

ALEXANDER DODDS COMPANY
3000 Walkent Drive NW
Grand Rapids, MI 49504-1453
1-616-784-6000
1-800-84-DODDS Toll Free
1-616-784-8329 Fax

INSTRUCTIONS FOR THE OPERATION OF
DODDS AUTOMATIC DOVETAILER

Serial Numbers
C-1341 - C-1867

INDEX

	<u>Page No.</u>
INSTALLATION	1
LUBRICATION	1
(Supplementary Lubricating Instructions for the Spindle Housing)	2
CONNECTING AIR	3
OPERATING MACHINE	3
CAMS	3
CUTTING DRAWER SIDES	4
CUTTING DRAWER FRONTS AND BACKS	4
CUTTING SERPENTINE DRAWER FRONTS	5
CUTTING BLIND DOVETAILS	5
CUTTING LIPPED DRAWER FRONTS	6
ADJUSTMENTS	
Variable Feed	6
Cutter Wear	6
Centering Cut on Drawer Sides	6
Automatic Cycling	7
Carriage Lock	7
Incline and Incline Back	7
Bits (Insertion and Removal)	7
Spindles	8
Bearing	8
PARTS LIST	9
PRODUCT ILLUSTRATIONS	14 - 20
REMOVAL OF SPINDLES AND BEARINGS IN BALL BEARING SPINDLE ASSEMBLY	21
WIRING DIAGRAM	23
MICRO-FOG LUBRICATOR	24
PROCEDURE FOR CENTERING AND STRAIGHTENING DOVETAIL CUTS	25
DUST COLLECTOR	26

INSTRUCTIONS FOR GRINDING DOVETAIL BITS

PRODUCT CATALOGS

1. Stearns Installation and Maintenance Data Sheet No. 300, 12/1/64
2. Norgren, Micro-Fog Lubricator, Type 10-009 NIP 28/8M/6-63/N
3. Norgren, Liquid Level Control Switch, Type 18-023 NIP 48c/6M/10-66/N
4. Norgren, Automatic Drain Filter, Type 12-001 NIP 46a/5M/6-66/N
5. Norgren, Pressure Regulator, Type 11-002 NIP 6e/60M/3-66/N

INSTRUCTIONS FOR INSTALLATION, LUBRICATION AND OPERATION
OF DODDS AUTOMATIC DOVETAILER
FOR CUTTING DRAWER FRONTS, BACKS AND SIDES

This DODDS dovetailer has been completely tested under power, and it is in perfect operating condition before shipment. It will give excellent service for a long time if treated with reasonable care. After the machine arrives, inspect it for any damage in shipment, and if any, make immediate claim to carrier.

INSTALLATION

The machine should be accurately leveled. It may be bolted down if desired or required. Remove the wooden blocks. Be sure there is sufficient oil in cam gear housing. After correct current has been connected, check the machine for rotation by using the cutters as a guide. **DO NOT START MACHINE BEFORE FOLLOWING LUBRICATION INSTRUCTIONS.**

LUBRICATION

The clamp head and carriage operate on ball bushings and are life lubricated at the factory. If any dragging develops, a few drops of oil on the shafts will correct it.

We do not recommend any particular brand of oil and grease; therefore, the following should serve only as a guide in using equivalent types and grades of oil and grease. The spindle housing unit is a closed system and the parts are lubricated by a Norgren Micro-Fog oil mist lubricator.

- *Spindle Housing - Use Mobilmist #36 oil or exact equivalent in the Norgren Micro-Fog lubricator.
- Bearings - Use Mobilux No. 2 or equivalent.
- Gear Reducer - Use Mobil Compound FF or equivalent.
- Cam Gear Housing - Use Mobil Compound FF or equivalent.
- Air Line Lubricator - Use Model DTE Heavy Medium or equivalent.
- Spindle Motor - Use Mobilplex Ep No. 1 or equivalent.

Item numbers 2 and 3 of the following have been serviced before shipment of the machine. (EXCEPT 2B WHICH SHOULD BE FILLED TO PROPER LEVEL BEFORE OPERATING THE MACHINE.)

1. Check each week:

- a. The oil level of the Norgren Micro-Fog lubricator.
The oil level must always be visible in the gauge glass.

***WE CANNOT BE RESPONSIBLE FOR DAMAGE RESULTING FROM USE OF IMPROPER OIL IN THE SPINDLE HOUSING UNIT.**

* * * * *

SUPPLEMENTARY LUBRICATING INSTRUCTIONS
FOR THE SPINDLE HOUSING

The C.A. Norgren Company has tested the lubricants listed below only to determine their suitability for use in the Norgren Micro-Fog lubricator.

* *Chevron*

Socony Mobil Oil Company
Texas Company
Standard Oil Company
Gulf Oil Corporation
Shell Oil Company

INDUSTRIAL R #0 #115

Mobilmist #36
Regal F (R & O) oil
Stanoil 52 oil
Harmony 69 oil
Tellus 69 (Code 3795) oil

The recommended rate of the oil flow in the sight glass on the lubricator is a constant flow of oil at 15 PSI. The lubricator has been adjusted for this rate of oil flow at the factory. Use only fresh, clean oil. CHECK EACH DAY TO BE SURE THAT OIL IS FLOWING THROUGH LUBRICATOR.

The air pressure for the Norgren Micro-Fog system should be between 10 and 20 PSI on the large gauge and 12 PSI on the small gauge. Do not exceed 20 PSI. The large regulator of the Micro-Fog system is for the fog lubrication. The small regulator of the Micro-Fog system is for the pressure jets which force the fog lubrication to the proper bearing surfaces in the spindle unit.

NOTE: AIR PRESSURE OUT OF MICROFOG UNIT SHOULD BE AT 20" OF WATER
Do not let the oil accumulate more than 2" deep in the bottom *COLUMN*, of the spindle drive box. Drain at regular intervals.

IT IS VERY IMPORTANT THAT ANY OF THE ABOVE SPECIFIC OILS OR THEIR EXACT EQUIVALENT BE USED IN THE NORGREN MICRO-FOG LUBRICATOR FOR LUBRICATING THE PARTS IN THE ENCLOSED SPINDLE HOUSING. WHEN REFILLING, IT IS VERY IMPORTANT THAT THE LUBRICATOR BE CLEAN SO THAT NO SAWDUST OR FOREIGN MATTER GETS INTO THE RESERVOIR. IF OIL LINES BECOME CLOGGED, SERIOUS DAMAGE WILL RESULT TO SPINDLES, BEARINGS AND GEARS.

If you have any questions about the Norgren lubricating system, contact your local Norgren Representative.

* CURRENT RECOMMENDED OIL

2. Grease or oil every twelve months:
 - a. Check oil in gear reducer
 - b. Check oil level of cam gear housing unit
3. Grease once a year:
 - a. Bearings on cam gear housing unit
 - b. Motor for driving spindles
4. Cam followers are factory lubricated and require no attention.

CONNECTING AIR

Pipe air to the air fitting on the pressure regulator located on the rear of the machine. Adjust the air pressure to 75 pounds for the clamping. The amount of pressure can be increased or decreased according to your experience. This machine is equipped with an air line lubricator which is adjusted to allow a few drops of oil to pass into the air line every three or four days.

TO OPERATE MACHINE

After the installation, lubrication and air connecting instructions have been followed, the machine is ready to operate. Turn selector switch to HAND and then button marked START. Depress foot switch and release. The machine will now make one cycle.

To obtain maximum efficiency of this machine, we recommend the use of DODDS dovetail bits only. These bits are manufactured specifically for this machine. The use of other bits may result in costly repairs.

CAMS

The machine when shipped is set up for cutting drawer sides. Cam number 2 is stamped for the stock thickness (refer to page 15, items 86 and 87). Item 86 is the location of Cam number 2 or number 3. Item 87 is the location of Cam number 1. Only number 3 Cam is used when cutting drawer fronts and backs. The numbers on the Cams should always be on the same side as the lock nut. Be sure that the cams are attached securely in place before operating the machine. WHEN USING CAMS, NUMBERS 1 AND 2, HAVE CARRIAGE LOCK FULLY RETARDED OR REMOVED. (Refer to page 20, item number 21.)

CUTTING DRAWER SIDES

Cam numbers 1 and 2 are used when cutting drawer sides. (Refer to section on Cams for proper setup.) Insert vertically by pairs, back to back, two or four drawer sides, depending upon the size of the machine and the width of the drawer sides, inside the front clamp and against the stop on one side when cutting two drawer sides and against the stops on both sides when cutting four drawer sides. Set the edges of the drawer sides firmly against the stops (page 14, items 20L or 20R) and resting on the finger plate. Depress the foot pedal and clamping and cutting operate simultaneously. At the end of each cycle, the clamping is automatically released and the feed operation stops. The stock is then turned upside down and the other ends are cut in the same manner. (Refer to page 14, items 20L and 20R.) Adjust these stops for position of the dovetail tenon across the width of the stock. To center the tenons when cutting two drawer sides at one time, loosen the two nuts (refer to page 19, item 93) on the Cam Follower, and move Cam Follower forward or backward. The adjustment usually required is very slight. WHEN USING CAMS NUMBER 1 AND 2, HAVE CARRIAGE LOCK FULLY RETARDED OR REMOVED. (Refer to page 20, item 21).*

CUTTING DRAWER FRONTS AND BACKS

Only number 3 Cam is used when cutting drawer fronts and backs. (Refer to section on Cams for proper setup.) The aluminum stop, (page 18, items 50 and 51) furnished with the machine, replaces the front clamp (page 15, figure 2, items 80 and 81) used in cutting drawer sides. This stop is fastened to each end of the head with the cap screws from stops 20R and 20L and is adjustable for depth of cut. (Refer to page 18, item 52). When using Cam number 3, be sure to secure carriage with carriage lock (refer to page 20, item 21). Face the back of the machine and place horizontally two drawer fronts or backs, one on each side of the table under the top clamp and against the front and side stops. Make the cut and the stock is then turned around and the other ends are cut in the same way. The two threaded rods between the two top cylinders on the head are used when cutting one drawer front or back at a time. Insert one drawer front or back under center of clamp bar (refer to page 18, item 75). Then, cycle machine and stop in clamped position. To stop machine, depress foot pedal and hold and then push stop button and stop machine.

Turn down nuts on threaded rods finger tight and then retard 1/6 of a turn and lock with lock nut. Start the machine and finish cycle. This adjustment of the threaded rods prevents the pressure bar from tilting. (Refer to page 15, figure 2, items 18 and 19.) These items are the stops for adjusting the position of the dovetails across the width of the stock.

CUTTING SERPENTINE DRAWER FRONTS

The table should be in the same position as used in cutting regular drawer fronts. Remove incline back (refer to page 18, item 67) and insert your jig. The cutting is completed in the same manner as in cutting regular drawer fronts.

If necessary, we can furnish a finger plate to be attached to the finger board. (Refer to page 18, item 66.)

CUTTING BLIND DOVETAILS

The same cams are used in cutting drawer fronts and backs or drawer sides.

1. The carriage locking screw should be fully retarded (unlocked). This step is very important. (Refer to page 29, item 21.)
2. The number 1 regular dovetail cam is replaced with cam marked number 2 BLIND.
3. The number 2 regular dovetail cam is replaced with cam marked number 2 BLIND.
4. When cutting drawer sides, the clamp used in cutting regular dovetails on drawer sides is attached in place (refer to page 15, figure 2, items 80 and 81) and the stops for positioning the dovetails across the width of the stock are placed in their proper location and ready to make the Blind Dovetail Cut in the drawer sides. Drawer sides must be at least 5/8" thick.
5. When cutting drawer fronts or backs, the clamp for the drawer sides and the stops for the drawer sides are removed. The aluminum finger stops used in cutting regular dovetails on the drawer fronts and backs (refer to page 18, items 50 and 51) is attached to the head with a 3/4" wooden filler strip inserted between the head and the aluminum stop. BE SURE TO USE THE HOLES THAT PLACE THE ALUMINUM FINGERS ABOVE THE CUTTERS. This stop is adjusted by means of elongated slots and may be adjusted to the desired depth. After the stops for positioning the dovetails across the width of the stock are placed in their proper positions, the machine is ready to make the Blind Dovetail Cut.

CUTTING LIPPED DRAWER FRONTS

These drawer fronts are cut in the same manner as the regular drawer fronts. The regular stop on the machine will accommodate drawers with the lips up to 1-3/4" long.

ADJUSTMENTS

Variable Feed

The feed speed can be varied to any rate of speed between 10 and 25 CPM to most efficiently handle the dovetailing to be done. The speed is altered by turning the hand wheel of the speed selector drive which is located in front of the feed motor. (Refer to page 15, figure 3, item 95.) When the feed speed is changed, the carriage may not stop in the proper place. The Cam (refer to page 18, item 111) may be advanced or retarded to stop the carriage in the proper position.

The pin of the cam roller, (refer to page 18, figure 12, item 88), and the shaft of the cam (refer to page 18, item 86), should be in line.

CUTTER WEAR

The cutters, as they are sharpened, become smaller and this results in a smaller mortise and a larger tenon so that the dovetail joint is too tight. To remedy this condition, the 1/2" machine screw with lock nut, which is located inside the frame against the slide on the side of the machine where the motor is (refer to page 17, item 17) should be turned slightly until the correct adjustment is made.

Keep your bits sharpened to a keen edge and they will last much longer. A dull tool wears fast and is hard on the machine. Always sharpen the complete set of cutters to keep them uniform in size.

If burning occurs when the cutters are sharp, it indicates that the feed is too slow.

TO CENTER CUT ON DRAWER SIDES

See instructions for cutting drawer sides.

AUTOMATIC CYCLING

When the selector switch marked AUTO is turned to the right, the machine will cycle and then delay from 1/5 of a second to three minutes and then recycle automatically. The length of the delay is controlled for loading and unloading by adjusting slotted screw in cycle-timer (refer to page 20, cycle timer).

CARRIAGE LOCK

WHEN USING CAMS NUMBERS 1 AND 2, FOR CUTTING DRAWER SIDES, BE SURE TO HAVE THE CARRIAGE LOCK FULLY RETARDED OR REMOVED. (Refer to page 20, item 21.)

INCLINE AND INCLINE BACK

Incline (refer to page 18, item 67A) and Incline Back (refer to page 18, item 67) can be turned over to make a flat table by removing bolt (refer to page 18, item 68). Bolts in the fingerboard (refer to page 18, item 57H) adjust the table for height or mortise cut.

BITS (INSERTION AND REMOVAL)

Remove finger plate (refer to page 13, item 150) to facilitate the removing or inserting of the dovetail bits.

Open the two toggle clamps located on the front of the machine and remove the finger plate. Hold spindles stationary by inserting crank, which is furnished with the machine, into the end of the Drive Shaft and have handle of crank against frame. Loosen each bit. Pull crank out slightly so that the handle misses the frame. Hold each bit and crank out or in. CAUTION--REMOVE CRANK BEFORE STARTING MACHINE.

To obtain maximum efficiency of this machine, we recommend the use of DODDS dovetail bits only. These bits are manufactured specifically for this machine. The use of other bits may result in costly repairs.

SPINDLES

The spindles operate in radial ball bearings and are at a fixed height. The spindle unit can be removed from the drive housing by disconnecting the main oil line at the oil manifold and then removing the bolts connecting the spindle unit to the drive housing. (See instructions, To Remove Spindles and Bearings in Ball Bearing Spindle Assembly, page 21.)

Do not permit sawdust to collect in top of spindles as this may result in breakage of the bits.

BEARINGS

The ball bearings in the spindle unit were engineered for this application and we, therefore, recommend that replacements be purchased from us. We cannot be responsible for damage resulting from the use of or the premature wear of bearings not obtained from us.

PARTS LIST FOR DODDS AUTOMATIC DOVETAILER

In order to maintain accuracy, it is necessary and economical to replace worn parts. This listing has been prepared to simplify the ordering of parts.

WHEN ORDERING

1. List serial number of machine.
2. List size of the machine (number of spindles).
3. List number and name of part as shown in listing.
4. Specify amount wanted.

As some parts are fitted in assembly, these parts will be finished as far as possible with allowance for fitting where required.

<u>PART NUMBER</u>	<u>NAME OF PART</u>
17	1/2" x 3" sq. head set screw (for adjusting cutter wear)
19	Rear stop for drawer fronts and backs
20L	Left stop for drawer sides
20R	Right stop for drawer sides
27	Dovetail bits To obtain maximum efficiency of this machine, we recommend the use of DODDS dovetail bits only. These bits are manufactured specifically for this machine. The use of other bits may result in costly repairs. When ordering bits, give the number required.
12 spindle machine	6 right hand - 6 left hand
15 spindle machine	6 right hand - 9 left hand
20 spindle machine	8 right hand - 12 left hand
25 spindle machine	10 right hand - 15 left hand

The size of the bit, as stamped, or the size of the bit ordered, will cut that length tenon or that height mortise, whether ST or OT. The OT has a sharper angle than the ST type. Dovetail bits are available in High Speed Steel, and with Tungsten Carbide Tips. The High Speed Steel bits used on this machine have a 5/16" - 24 thread shank.

28	Spindle drive motor
30	V-belt - B-46
50	Finger stop for drawer fronts and backs
51	Finger stop bracket
52	3/8" - 16 NC x 3/4" hex head cap screw
53	3/8" - 16 NC x 3/4" hex head cap screw
55 & 56	1-1/2" shaft for slide
57	Slide
57A	Slide tie bar
57B	3/4" tension spring #170
57H	Incline adjusting bracket
58	1-1/2" Thompson ball bushing
59	1-1/2" dust seal
60 & 61	3/4" shaft for fingerboard
62, 65 & 66	Fingerboard
63 & 64	3/4 bearing block
67	Incline back
67A	Incline
68	1/2" - 13 NC x 1" hex head cap screw
69	Head
71 & 72	1/2" x 1-1/4" hex head cap screw

73 Air cylinder OOFNC 4002
75 Top clamp bar
76 Air cylinder 11 ENC 2001
78 Front clamp bar
80 Front chipbreaker
81 Back chipbreaker
82 5/16" x 1-1/2" stripper bolt
83 Compression spring C 43 C
84 Chipbreaker hangers
85 5/16" x 1-3/4" hollow head set screw & nut
86 Straight motion cams, #2 for cutting
drawer sides
- 5/16" drawer sides - 1/2 " drawer sides
- 3/8 " drawer sides - 9/16" drawer sides
- 7/16" drawer sides - 5/8 " drawer sides
Cam for cutting one drawer side to 1-1/16"
thick Blind Dovetail
- #3 Cam for cutting drawer fronts and backs
87 Side motion cam
- #1 Cam for regular dovetails
- #1 Cam for blind dovetails
88 Straight motion cam follower
89 Side motion cam follower
90 Side motion cam follower bracket
91 3/8" x 1" cap screws
92 Straight motion cam follower bracket
93 5/8" x 11 NC hex nuts
94 1/3 or 1/2 HP brake motor
95 Speed selector control

96	V-Belt A 38 or A 35
97	6 M speed selector sheave
102	Speed reducer SB 1860 C
103	Sprocket 82 B 30
104	Cam gear housing
105	Single roller chain #35
106	Sprocket 35 B 30
107	Long cam shaft
108	Helical Mitre Gear LSA 104 R
109	Helical Mitre Gear LSA 104 L
110	Short cam shaft
111	Limit-switch cam
112	Limit-switch CR9440K1J1
116	Pilot valve BV 40606-A
117	Speed selector 4C
119	Foot switch AW 6
150	Finger plate
151	Finger plate clamp
152	Drive gear
153	Pinion
154	Lower gear regular spindles (L-R-R-L)
155	Upper gear regular spindles (L-R-R-L)
156	Lower gear drive spindle LH
157	Upper gear drive spindle LH
158	Upper spindle bearing (see *)
159	Lower spindle bearing

*These are special bearings and must be purchased from the Alexander Dodds Company or their authorized representative. We cannot be responsible for damage resulting from the use of other bearings.

- 161 Drive cover window
- 162 Bearing lock collar (R & L)
- 163 Bearing spacer
- 164 Top bearing cover
- 165 Upper bearing housing
- 167 Lower bearing housing
- 169 Drive spindle bearing housing




Fig. 1

Fig. 2.




Fig. 3.




Fig. 4.





Fig. 5.






Fig. 6.




Fig 12






Fig. 12





TO REMOVE SPINDLES AND BEARINGS
IN BALL BEARING SPINDLE ASSEMBLY

This is a high speed precision unit and it should be treated with reasonable care. When parts are replaced, be sure that all parts are clean before reassembling the unit.


1. Secure drive shaft with crank and remove all spindle nuts. (Please note that the nuts are both right and left hand.)
2. Disconnect the 1/4" oil lines from back of spindle unit.
3. Remove the two 1/4" dowel pins from the front cover of the drive box and remove the Allen Head Cap screws holding the spindle assembly to the drive box.
4. Remove spindle assembly and secure in vise, with front cover up. (Be careful that you do not lose bearing spacers.) Remove the front cover after removing the two Allen Head Cap screws holding the bearing housings for the drive spindles.
- 4A. For replacing bearings, pinion gear, or other parts in the drive spindle area, refer to instructions on the following page.
5. Remove the four Allen Head cap screws from the lower bearing plate. Remove lower bearing plate with the spindles by inserting a 1/4" rod in top of spindle and then tapping lightly so that all spindles are removed at one time with the plate.
6. Remove spindle with lower bearing and replace bearing.
7. Replace upper bearing by removing the Allen Head cap screws holding the two upper plates. (Be sure numbers on left hand side of plates and castings are located together.) Separate the plates and remove old bearing. When replacing new bearing, remove one seal and insert in bearing plate with open side down.
8. File off any burrs that may have occurred when the parts were disassembled.
9. After replacing the parts needed, PRIME all spindle gears, pinions, and drive gears with Gulf Harmony #69 oil, or exact equivalent.

10. Reassemble spindle assembly by reversing the above procedure.
11. Use a straight edge on top of spindles and make certain that all of the spindles are level. The new spindle or spindles may be slightly higher. If so, file level with other spindles with a flat file.

THE DRIVE GEAR AND PINION ARE MESHED CORRECTLY WHEN THE NUT ON THE UPPER PART OF THE DRIVE SPINDLE WILL MOVE FREELY BACK AND FORTH APPROXIMATELY 1/32".



Emergency Stop



Page 21





Figure 24

PROCEDURE FOR CANTING AND SMOOTHING DOWNTAIL CHIPS



**Bottom view of drawer cutter as placed in mechanism
(Exaggerated Dovetail conditions shown)**

CONDITION I

Too much flat area at front of stock.

Correction:

Hold roller B level and loosen nut P. Turn nut P toward bracket C the desired amount and retighten nut P. (With 1/8 of a turn of either nut will move carriage ahead or back approximately 1/64".)

CONDITION II

Correction:

Too much flat area at back of stock.

Hold roller B level and loosen nut P. Turn nut P toward bracket C the desired amount. (CAUTION: Do not adjust nut P beyond point where there is no flat on back side of cut; see description under Condition I. If the carriage is shifted too far forward, it will catch the square boxes at the forward end of the cut.) Retighten nut P.

CONDITION III

Correction:

End of dovetail is not rounding properly as the dovetail appears to lean to the left when stock is held in position as shown.


Loosen screw R and slide bracket C downward slightly in slot A. Retighten screws and check the cut. Continue this procedure until cut is rounding properly.

CONDITION IV

Correction:


End of dovetail is not rounding properly as the dovetail appears to lean to the right when stock is held in position as shown.

Loosen screw R and slide bracket C upward slightly in slot A. Retighten screws and check the cut. Continue this procedure until cut is rounding properly.





1/2" N.P.T. ~~1/2" N.P.T.~~ ~~1/2" N.P.T.~~
1/2" N.P.T. ~~1/2" N.P.T.~~ ~~1/2" N.P.T.~~

ALEXANDER DODDS CO.	
NAME	GRAND RAPIDS, MICHIGAN
NAME	GRAND RAPIDS, MICHIGAN
NAME	GRAND RAPIDS, MICHIGAN
MATERIAL	STEEL
SCALE NAME	STEEL
UNITS	INCHES



Instructions for grinding DOVETAIL BITS



IMPORTANT

Keep your bits sharpened at all times — a dull bit results in tear-out, improperly fitting joints, burning and shorter bit life.

We recommend a 7" diameter, 100 grit wheel for this application. These wheels can be furnished by us at a nominal cost.

Alexander Dodds Company
MANUFACTURERS OF
Woodworking Machinery

1014 SCRIBNER AVE., N.W. PHONE 459-7344 — AREA CODE 616
GRAND RAPIDS, MICHIGAN 49504 U.S.A.



MICRO-FOG LUBRICATOR TYPE 10-001

INSTALLATION

Install the lubricator near the machine it will serve. A filter and regulator should be installed directly ahead of it in the air pressure line. Note the arrow on the body which indicates the direction of the flow.

A 1/4" supply line is ample to take care of maximum flows mentioned. Be sure to use hoses and fittings long enough to allow free air flow. Do not install any valves, pressure regulators or other restrictions between the lubricator and the point of fog application. Oil-laden vapors due to the over lubrication must be kept in service (gasoline, kerosene, etc.), providing the piping does not restrict oil to the filter.

OPERATION

The minimum operating pressure is 5 psig for all sizes. The maximum pressure is 20 psig for 1/4" size, 25 psig for 1/2", and 30 psig for 3/4" size.

CARDED LUBRICATING CAPACITY

The only adjustment on this lubricator is the bypass adjustment screw (1). This can be done with a 1/16" Allen wrench. To increase the output, turn the bypass adjustment clockwise. To decrease turn it counter-clockwise direction.

LUBRICANT	TEMPERATURE	AMOUNT	MAX. FLOW
Gasoline	60° F.	1 cfm	40
Kerosene	70° F.	1.5 cfm	100
Mineral Oil	70° F.	1.5 cfm	100
Gasoline	70° F.	5.0 cfm	300
Kerosene	70° F.	5.0 cfm	300
Gasoline	70° F.	2.5 cfm	70
Kerosene	70° F.	7.5 cfm	300

The flow is controlled by a combination of pressure and bypass air. The number of carburetors will determine the correct pressure for the lubricator. The pressure in the fog distribution system at a point furthest from the lubricator should be at least a pressure of eight inches water column. To determine this install a manometer gauge in the system or use the method described in the Design Manual NP-10.

To adjust the fog output, reduce the pressure on the lubricator, then open the bypass valve and the fog distribution system to assure again pressure at least 8 inches water column.

MAINTENANCE

To service or to clean the lubricator disassemble as follows. Shut off the air pressure. Remove the bowl or reservoir and unscrew the diffusion plug (1). Then unscrew the suction tube (2). Take out the regulator screw (3) and push the venturi plug (4) out counter-clockwise. Turn the bypass adjusting screw (5) so it is removed not all the way.

Before reassembling clean and check each part carefully. If any are damaged replace them, ordering from the Parts List or the reverse side of this sheet. To clean the Safety-Check valve fit it in a jet solvent solvent such as kerosene. DO NOT USE acetone, benzene, dioxane, ethyl acetate, lighter fluid, acetone, nitrolic acid, carbon tetrachloride, etc., as these solvents may deteriorate the parts.

C. A. NORGREN CO.

2482 FOURTH STREET


ENGLEWOOD, COLORADO



PARTS

MICRO-FOG LUBRICATOR

TYPE 10-009



REPAIR KIT

1. Sight-fog dome	1648-01	\$.50
2. Sight-fog dome gasket	405-01	
4. Filter plate gasket - KIT	1956-01	
5. By-pass adjusting screw (with "O" ring)	766-01	
6. Sight line gasket	3562-01	
7. Vacuum plug 'O' ring	1741-01	
8. Filter plate gasket - Tank	1911-01	
9. Reservoir gasket	1929-01	

REPAIR KIT #111 LBVB1 (MIL-KIT CLASS 58)

10 vacuum cap	2272-02	\$.50
45 gauge cap	2273-01	\$.50
141 gauge cap 2P2 (lower cap)	2273-01	\$.75
(Kit contains backings 18 and 21, nut 19 and 22, gauge glass M. gasket 24, indicator ball 26)		

REPLACEMENT PARTS

3. Filter plug (with gasket)	1626-02	\$.50
5. By-pass adjusting screw (with "O" ring)	1662-02	\$.50
7. Screw (per set of 4)	1774-02	.00
10. Sight line (with gasket 9)		
for 10 gauge cap	1091-01	\$.75
for 45 gauge cap	1091-01	\$.75
for 141 gauge cap	1042-01	\$.75
for 282 gauge cap	1042-01	\$.75
12. Vacuum plug (with "O" ring)		
1" pipe size	1672-01	\$.00
1/2" pipe size	1673-01	.45
13. Diaphragm plug for 1" pipe size	1685-01	\$.50
for 1" and 1" pipe sizes	1753-01	\$.50
14. Filter plug (with gasket 15)	1807-02	\$ 1.10
17. Upper gauge glass bracket	2087-01	\$ 1.00
25. Lower gauge glass bracket		
19 gauge and 45 gauge cap	2087-01	\$ 1.00
141 gauge and 282 gauge cap	2087-01	\$ 1.00
26. Drain cock	614-01	.15
27. Pipe plug	136-01	.15
28. Reservoir assembly - 19 gauge cap	648-25	\$ 1.40
45 gauge cap	648-33	.75
141 gauge cap	1106-01	.50
282 gauge cap	1208-01	.50

PARTS NOT NORMALLY REPLACED

- B. Body

Turned 30 days net. Prices subject to change without notice.

These prices are net price outside of the United States.

C. A. NORGRREN CO.

100 SOUTH BROAD STREET

INGLEWOOD, COLORADO

LIQUID LEVEL CONTROL SWITCH

Type 18-023



1. Mount switch to tank body.
 2. Position float (1) following oil gauge line levels of the tank as required.
 3. Thread float (1) into float stem until it bottoms through opening in bottom of switch body (see Fig. 1).
 4. Mount float (1) through center opening in switch body to the float stems in switch body.
 5. While holding float (1) against gauge line, open switch (2) with a small screwdriver inserted between float (1) and gauge line (see Fig. 2).
 6. Turn switch (2) clockwise until the float (1) is firmly seated on the gauge line. This will set the float (1) height and cause the contacts to close. Turn switch (2) counter-clockwise until the float (1) has moved enough so that the float (1) contacts are again open.
 7. Open switch (2) with a small screwdriver if the gauge line goes up or down. Turn switch (2) until switch is threaded in either an oil gauge or storage tank to prevent float from floating. This same rule in holding open.
 8. To prevent damage, do not apply water pressure to the float (1). If water is applied to the float (1), it will damage the float (1) and cause the switch to stick.
 9. Replace switch (2) as initially.
 10. Replace gauge line. Scale markings must remain on the new gauge line. Set the float height initially and measure from markings on the gauge line to the contacts.
- NOTE: For strong tank top values no original gauge line is used.

These switches are completely assembled and guaranteed to be 100% operational. However, small scratches from shipping may appear on the gauge line. If this occurs, sand the line with fine sand paper.

$0.01 = 0.0254 \text{ cm} \quad 0.02 = 0.0508 \text{ cm}$
0.03 = 0.0762 cm

Guaranteed performance guaranteed.

We invite an automatic parts distributor.



C. A. NORGREN CO.
5400 SOUTH DELAWARE
WILTON, COLORADO

North's largest manufacturer of precision fittings, regulators, valves and control valves. Give us these reasons.

WIRING DIAGRAM FOR LIQUID LEVEL CONTROL SWITCH Type 18-023 & 18-024



PARTS LIST

	Part No.	Qty
1	Flange	320002
2	Sleeve	320004
3	Nut	1331-71
4	Bung	320003
5	Stem Assembly	181414
6	Adapter (3/4" NPT to 1/2" NPT male) (1/2" NPT female)	320005
7	Indicator (Not in 18-024 model)	1332-29
8	Base	320007


Positive float contact configuration is the same as the 18-021 3-wire liquid level control switch. Contact sequence will be through the float and stem while within the float or in an lower point of float. Normally closed contacts will be between the float and stem or other position of the float.

CONTACT POSITION

Indicator and Indicator float contacts are open at float level. Other contacts (float, bellows float and base) contact pressure is 1 psi to activate (with normally closed contacts all contacts are open).

Operating - 4.5 to 11.5 V
Resistance - 500 ohms max

This switch can be used over a wide range of liquid levels.



Wiring Diagram (Float Down)


PRINTED IN U.S.A.



C.A. Norgren Co./5400 South Delaware/Littleton, Colorado

PRESSURE REGULATOR

Type 11-002



Parts List

	Part No.	QTY	Part No.	QTY
REPAIR KITS				
1 and 2 main seating	529-03	—	520-03	5.00
1 and 2 seating — — —	528-03	—	5.20	1.70
1 seat retainer — — — —	515-03	—	516-03	1.00
2 seating — — — — —	515-03	—	515-03	1.25
2 and 3 seat retainer — — —	530-03	—	530-03	1.75
4 and 5 seat retainer — — —	530-03	—	530-03	1.75
KIT CONTENT				
6 Pin hardware — — — —	661-01	461-01	482-01	—
12 "D" ring — — — — —	212-01	105-01	715-01	—
14 Valve (See Below) "D" ring 81%	210-01	497-01	156-01	—
15 Sealing sleeve — — — —	509-01	719-01	511-01	—
17 Valve spring — — — —	508-01	497-01	156-01	—
18 "D" ring for plug — — —	036-01	712-01	521-01	—
REPLACEMENT PARTS				
1 Adjusting screw — — — —	1059-01	1074-01	—	50
Adjusting screw — — —	—	—	1074-00	75
2 Lock nut — — — — —	146-01	1066-01	159-01	0*
3 Retaining sleeve — — — —	1447-01	131-01	—	50
Retaining sleeve — — —	—	—	6001	50
4 Valve seat retainer 3/8" plug — —	1400-01	1361-01	—	50
3/8" plug — — —	—	—	1524-01	1.50
5/8" plug — — —	177-01	477-01	—	50
1-1/8" plug — — —	—	—	478-01	50
2-1/8" plug — — —	1409-01	1360-01	—	50
5 Intermediate liquid seat				
123" plug — — —	524-01	515-01	—	50
123" plug — — —	—	—	524-01	40
7 Intermediate liquid 3/8" plug — —	197-01	190-01	—	50
3/8" plug — — —	—	—	190-01	50
1/2" plug — — —	504-01	104-01	—	50
1/2" compound spring 1/2" plug — —	902-01	103-01	—	50
1/2" plug — — —	—	—	903-01	1.00
8 Valve spring seat — — — —	479-01	470-01	—	50
Excess spring seat — — — — —	—	—	470-01	1.50
10 Seat from retainer — — — —	2300-01	2301-01	2300-01	—
11 Valve seat — — — —	485-01	—	—	50
Valve seat — — — — —	—	104-01	—	50
Valve seat — — — — —	—	—	104-01	50
12 Valve guide plug — — — —	612-01	—	—	500
Valve guide plug — — — — —	—	103-01	—	500
Valve guide plug — — — — —	—	—	103-01	500
PARTS NOT NORMALLY REPLACED				
1 Stem — — — — —	171-01	479-02	472-01	—
Body — — — — —	—	—	—	—

AMERICAN LEADERSHIP
PROUDLY MADE IN U.S.A.

Temp. - 20 degrees. Please subject to change without notice.
These valves are not good valves of the United States.



INSTRUCTIONS and PARTS LIST

AUTOMATIC-DRAIN FILTER

Type 12-001

INSTALLATION

Install the filter as close as possible to the condenser or in any leg removed from the condenser coil discharge. Run the filter on one line with maximum pressure of 10 psi. Do not run the filter with the temperature below 40° F. or above 140° F. Recommended filters are the following:

OPERATION

No adjustments are necessary on the automatic drain valve. The pressure and operating temperature withstands up to 100° F. in freezing, and a working range of 40° to 140° F.

ADJUSTMENTS

The filter drains under the influence of a rising pressure. To adjust the filter, disassemble the pressure and remove the float support as the figure shows, or remove the float valve (1) in the small case and take off the adjustment bolt (2) or (3). Then adjust the float assembly (2) or (3) so that the filter starts (1) at 40° F.



Important: Do not overadjust the float (1) at 40° F. or all the water leaving legs of the coil will deposit on the coil coils. Do not set a float switch specific higher than your operating temperature of 140° F. Run the maximum usual load. To change the operating point see page 14 this page.

When adjusting the float use sand and stone as a medium never use cement.

DANGER: The plastic parts used in this product can be damaged by extreme winter weather conditions which is static, because benzene vapors, strong solvents such as ether, acetone, and hydrocarbons or strong alkaline substances.

Before removing them and start with care. Remove. If not all damaged replace and, starting over we start up.






AUTOMATIC DRAIN ASSEMBLY

(Item 11500 Part 114)

After the drain assembly has been cleaned over the heat sink portion, replace over the screw (M) of automatic drain cap (I) from the drain body (J). Turn the drainage (K) so valve seat (L) will fit set upright. The gap between top of "L" & "K" must be the same as the gap between (L) and bottom of valve (J) surface.

Slowly rock per clockwise before assembly. Do not turn more than 1/4 turn each right.



AUTOMATIC-DRAIN FILTER

Type 12-001

Part List

NOTE: See "V" "V" "V" last page for K" and L" sizes.

REPAIR KIT

	Part No.	Qty.
1. Spout	100-000000000000	1
2. "O" ring	100-000000000000	1
3. Valve	100-000000000000	1
4. Lever	100-000000000000	1
5. Rod	100-000000000000	1
6. Plug	100-000000000000	1
7. Assembly	100-000000000000	1

REPLACEMENT PARTS

Part No.	Description	Size	Qty.
1. Spout	100-000000000000	1.000"	1
2. Plug	100-000000000000	1.000"	1
3. Lever	100-000000000000	1.000"	1
4. Valve	100-000000000000	1.000"	1
5. Rod	100-000000000000	1.000"	1
6. Plug	100-000000000000	1.000"	1
7. Lever	100-000000000000	1.000"	1
8. Valve	100-000000000000	1.000"	1
9. Rod	100-000000000000	1.000"	1
10. Plug	100-000000000000	1.000"	1
11. Lever	100-000000000000	1.000"	1
12. Valve	100-000000000000	1.000"	1
13. Rod	100-000000000000	1.000"	1
14. Plug	100-000000000000	1.000"	1
15. Lever	100-000000000000	1.000"	1
16. Valve	100-000000000000	1.000"	1
17. Rod	100-000000000000	1.000"	1
18. Plug	100-000000000000	1.000"	1
19. Lever	100-000000000000	1.000"	1
20. Valve	100-000000000000	1.000"	1

PARTS NOT PREVIOUSLY LISTED

1. Body

AUTOMATIC-DRAIN FILTER

Type 12-001

Part List

PIPE SIZES: 1/2", 3/4", 1", 1 1/2", 2", 3", 4", 6", 8", 10", 12"

REPAIR KIT

	Part No.	Qty.
15 "10" Plug	1922-01	1
21 Standard Disc Filter for External Mount Filter Body	1914-01	1
22 Standard Disc Filter for External Mount Filter Body	1915-01	1
23 "10" Plug	1923-01	1
24 "10" Plug	1924-01	1
25 Disc filter	1916-01	1
26 Disc valve	1917-01	1
27 Drain valve	1918-01	1
28 "10" Plug for drain assembly	1925-01	1
29 Flange nuts	1919-01	1

PIPE ASSEMBLY FOR WATER SUPPLY

	Part No.	Qty.
1 Elbow	1920-01	1
2 Tee	1921-01	1
3 Coupling	1922-01	1
4 Valve	1923-01	1
5 Coupling	1924-01	1

REPLACEMENT PARTS

	Part No.	Qty.
20 External Disc Filter Assembly	1910-01	1
21 Disc	1911-01	1
22 Disc assembly	1912-01	1
23 Disc assembly	1913-01	1
24 Retaining retainer	1914-01	1
25 Snap ring	1915-01	1
26 Valve assembly	1916-01	1
27 Retaining plate	1917-01	1
28 Snap assembly (Disc, Snap ring & Retaining ring)	1918-01	1
29 Disc assembly	1919-01	1
30 Snap assembly (Disc, Snap ring & Retaining ring)	1920-01	1
31 Disc	1921-01	1
32 Disc assembly	1922-01	1
33 Disc assembly	1923-01	1
34 Retaining plate	1924-01	1
35 Snap assembly (Disc, Snap ring & Retaining ring)	1925-01	1
36 Disc	1926-01	1
37 Disc assembly	1927-01	1
38 Disc assembly	1928-01	1
39 Disc	1929-01	1
40 Disc assembly	1930-01	1

PARTS NOT NORMALLY SHIPPED

41 Nuts

NOTE: All parts not listed will be shipped separately when ordered.
Please specify part number and quantity of the required items.



C.A. Norgren Co./500 South Deveraux/Littleton, Colorado

SECTION "A"—ADJUSTMENT FOR FRICTION DISC WEAR




FIG. A

HOW TO DETERMINE IF BRAKE IS IN NEED OF ADJUSTMENT

With current off, indicator at "NORMAL" or "ON" position indicates brake is in proper adjustment. When indicator is at the "ADJUST" position, or if marked increase in stopping time is noted, adjustment for wear is necessary. For brakes MOUNTED VERTICALLY, remove plastic release cover (if present) and depress lever or turn knob in release direction until spring pressure is felt. If indicator is at the "ADJUST" position at this point, adjust for wear.

SECTION A-1 STEPS



FIG. A-1

1. Remove pipe plug in Housing.
2. Insert Screwdriver and turn Adjusting Stud in Clockwise direction until indicator returns to the "ON" or "NORMAL" position.
3. Replace pipe plug.

SECTION A-2 STEPS




FIG. A-2

1. Remove pipe plug in Housing.
2. Insert Screwdriver and turn Adjusting Stud in Counter-Clockwise direction until indicator returns to the "ON" or "NORMAL" position. (For 46,000 Series, turn both Adjusting Studs equal amount until "on" position is reached.)
3. Replace pipe plug.

SECTION A-3 STEPS




FIG. A-3

1. Remove Manual Release Cover.
2. Loosen Locknut by turning in a Counter-Clockwise direction.
3. Insert Screwdriver into slot in Adjusting Stud and turn Clockwise until indicator is at approximately the "ON" position.
4. Tighten Locknut against Adjusting Stud and replace Manual Release Cover.

NOTES: 1. After brake has been adjusted, energize coil or depress plunger to close gap, then manually rotate shaft (DO NOT START MOTOR) and make certain that shaft rotates freely. This will insure sufficient turning clearance exists between frictional parts.

SECTION A-4 STEPS



FIG. A-4

1. Remove Housing.
2. Insert Screwdriver and turn Adjusting Stud in Clockwise direction until proper solenoid gap is attained. (See Table No. 2, SOLENOID GAPS.)
3. Replace Housing.

SECTION A-5 STEPS



FIG. A-5

1. Remove Housing.
2. Insert Screwdriver and turn Adjusting Stud in Counter-Clockwise direction until proper solenoid gap is attained. (See Table No. 2, SOLENOID GAPS.) (For 46,000 Series, turn both Adjusting Studs equal amount to maintain equal Solenoid Gaps.)
3. Replace Housing.

SECTION A-6 STEPS



FIG. A-6

1. Remove Housing.
2. Turn both Adjusting Screws equal amounts, approximately $\frac{1}{8}$ turn Clockwise, until proper solenoid gap is attained. (See Table No. 2, SOLENOID GAPS.)
3. Maximum torque may be obtained after operating brake several times, then turning Adjusting Screws very slightly either way and noting which position of fine adjustment provides satisfactory stopping without changing solenoid gap.
4. On Brakes with manual release Knob or button integral with housing, energize brake before installing Housing or turn housing so Knob assembly is about 20° to left of vertical centerline. After mating with endplate rotate housing to right to align with mounting studs. In other models, mount and attach.

2. WARNING: DO NOT ATTEMPT TO ALTER TORQUE RATING BY RE-ADJUSTING SOLENOID GAP.

SECTION "B"—RENEWAL OF FRICTION DISCS

STEPS

1. Follow Step 1 of Installation Instructions. (Section "D")
2. Follow Step 4 of Installation Instructions. (Section "D"), replacing old Friction Disc(s). To insure proper brake operation, be sure that Friction Discs move freely but not loosely, on hub. If snug, file internal edges lightly until free movement is attained.
3. "Turn Out" (reverse direction than for adjusting) Adjusting Stud or Screws to compensate for adjustments that had been made to brake (for proper direction, see AD-

JUSTMENT for WEAR, Section "A") before assembling Support Plate Assembly to Endplate. If it becomes difficult to tighten Support Plate Screws, "turn out" Adjusting Stud or Screws further. For 87,000 Series Brakes, simply mount Support Plate Assembly to Endplate.

4. Adjust brake as described in Section "A"—Adjustment for Wear. (See Table No. 1 for proper instruction section.) For 87,000 Series Brakes, lift Plunger until Solenoid Lever hits Stop. This will reset self-adjusting mechanism.
5. Replace Housing and Housing Screws.

SECTION "C"—COIL REPLACEMENT

SECTION C-1

FIGURE C-1
COIL ASSEMBLY

STEPS

1. Disconnect coil from power.
2. Remove retaining lock pin.
3. Lift plunger from base of frame.
4. Release top lock. Frame and coil assembly along with mounting hardware.
5. Slide coil away to load it free. To reassemble follow same order listed in reverse order. Be sure to use screw and bolt as recommended with correct base and cap.

SECTION C-2

FIGURE C-2
COIL ASSEMBLY

STEPS

1. Disconnect coil from coil.
2. Remove retaining lock pin.
3. Lift plunger from retaining ring.
4. Remove coil base. Coat base of frame with Thread Sealant and Anaerobic.
5. Press coil downward into center of base of frame until flat against frame. Retain retaining screw and retaining ring.
6. The new coil must be assembled in the same or lower position as the old coil. Top two retaining screws can be identified by numbers found on each section. To repeat see our surgery page for the **new** (see [Part 1](#)), Figure.

SECTION C-3

FIGURE C-3
COIL ASSEMBLY

STEPS

1. Disconnect retaining lock from coil.
2. Insert retaining sleeve support into slot in coil body and retighten lock pin.
3. Insert sleeve with lock sleeve into coil plunger and hold. Change frame. Turn coil counter-clockwise until coil is centered in base and seat with no resistance and tighten the lock.
4. Align coil to frame. If necessary, take additional care to center coils in frame slots.

TRROUBLE SHOOTING

FAILURE TO START

1. Under heat coil does not move.
2. Check to see if a resistor is present in circuit to coil by using a voltmeter.
3. Check to see if there is faulty return of current and ground connection.
4. Check to see if connections are tight.

EXCESSIVE HUMMING

1. Excessive noise may be due to heat coil not being held firmly to frame or to frame.

NO CURRENT

1. Check for absence of direct current between coil and frame.
2. Check to see if there have failed to be any shorting contacts. Check coil frame and plunger with multimeter to determine shorts.
3. Check for shorted coil frame contacts.


FAILURE TO RELEASE

1. Check pins and contacts after release of coil.

NOT HOLDING


1. If coil fails to hold or does not hold after one pulse or one cycle of coil.
2. Check for a shorted coil frame.
3. Check for shorted coil frame contacts. Check coil frame and plunger with multimeter to determine shorts. Check coil frame contacts.

SECTION "D"—INSTALLATION PROCEDURES



STEPS

1. Disassemble Starter—Remove Starter Housing, Housing Base Plate, Screw Assembly & Base Assembly, Pressure Plate, Friction Discs, Thrust Plates and Reluctance Discs. If desired, to facilitate assembly, remove pins and washers. All parts are provided with slotted holes which facilitate the use of lock nuts and lockwashers (allen wrench).
2. Attach Electromagnetic to Motor Shaft—Mounting sequence is same as shown below. Use 1/4" Allen wrench. In the case of Flange Mounted starters, mount these mounting brackets to frame and after repeated trials mount the complete assembly with respect to motor and start. Adjustments. The use of shims to achieve permanent position is suggested. Use all required torque wrenches. After installation is made, it is good to record initial measurements for future reference.
3. Connect Disc of Motor to Start Disc and set screw correctly. Note: Do not overtighten. If there are draft or required torque, turn bolt to 10 ft-lbs with proper draft. This would prevent loss of disc from face to 10 ft-lbs to 10 ft-lbs to 10 ft-lbs. Some friction discs are used to prevent spin or backlash due to gear runout. Due to gear runout, the load will exceed Brake Torque. If some friction is desired, use 10 ft-lbs.
4. Reassemble Friction Discs and Reluctance Discs in order and Pressure Plate. If mounted vertically, ensure proper fit. Proper alignment.



5. Mount Support Plate Assembly to baseplate and with suitable mounting hardware. See Fig. 2 for Series 100. Fig. 3 for Series 1000 for larger size starters.

Particular Attention and Warning Required

EXCITATION: If you connect to 120-240-480 volt AC power, never connect either the main switch or the main contactor coil to the main voltage. Use a 120 volt AC coil or 120 volt DC coil connected in parallel with the main voltage. If there is no receptacle, use a 120 volt AC coil connected in parallel with the main voltage. If there is no receptacle, use a 120 volt AC coil connected in parallel with the main voltage.

CONTROLLING AC SOLIDSTATE DEVS OR OTHER 200/240 VOLT/DC MOTORS

For use with 120 volt AC power, use 120 volt AC coil or 120 volt DC coil. If 240 volt AC power, use 240 volt AC coil. If 240 volt DC power, use 240 volt DC coil. If 480 volt AC power, use 480 volt AC coil. If 480 volt DC power, use 480 volt DC coil. If 120 volt DC power, use 120 volt DC coil. If 200 volt DC power, use 200 volt DC coil. If 240 volt DC power, use 240 volt DC coil. If 480 volt DC power, use 480 volt DC coil.

All starters with solidstate devices—single or multiple phases of permanent power supply to the compressor—will require 120 volt AC power source.



IF FRICTION LINING BREAKS

1. Do not try to "break-in" it now and wait until later.
2. Do not use—use a soft tool to clean and polish. If not, find ways of how to seal.
3. Clean bearings thoroughly from debris. If not, use clean solvent and repeat.
4. Do not use ordinary solvents since they contain strong acids. If not, then use a gentle solvent.
5. If further assistance is required, then call Stearns Electric Company for starting instructions on the basis of your particular application.

IF AN EXPLOSION PROOF BRAKE IS REQUIRED, SEE ATTACHED SECTION FOR EXPLORATION CHECK.

1. Mount Start Electromagnetic base on proper shaft and Disc assembly before machining surface of cylinder retaining road. Retain maximum clearance of 0.005". To prevent road damage to cylinder, use a small piece of lead wire or similar material.

2. Do not use glue, epoxy, resin, or any other type of adhesive on the metal. Disc assembly must be held firmly and correctly.

3. When using aluminum as structural plate, it is recommended that it be 1/8" thick. If it is aluminum, make sure that bearing clearance, bearing diameter, shaft width and thickness of base plate do not exceed 1/8" thick. If 1/8" thick plate is used, then the bearing clearance must be 0.005" and the shaft diameter must be 0.005" less than the bearing bore.

Stearns. ELECTRIC CORPORATION
100 EAST 42nd STREET • NEW YORK, NEW YORK 10017 • Telephone 645-3100

