
MX5117B

Spindle Shaper

Operation Manual



This manual has been prepared for the owner and operators of MX5117B Spindle Shaper.

Its purpose, aside from machine operation, is to promote safety using accepted operating and maintenance procedures. To obtain maximum life and efficiency from your Single spindle shaper and to aid in using it safely, please read this manual thoroughly and follow the instructions carefully.

Specifications

Max. Thickness of wood piece.....	120mm
Spindle Dia.....	Ø 35mm
Rotation speed of the main spindle.....	6000/8000/9200r/min
Dimension of the working table.....	1130*670mm
Motor power.....	4 / 5.5 / 7.5kw

The above specifications were current at the time this manual was published, but because of our policy of continuous improvement, our company reserves the right to change specifications at any time and without prior notice, without incurring obligations.

Unpacking and Clean up

1. Finish removing all contents from the shipping container. Do not discard any shipping material until the shaper is set up and running.
2. Inspect contents for shipping damage and report any damage or missing parts to your distributor and shipper.
3. Clean all protected parts with kerosene. Do not use gasoline, painter thinner, or any cellulose-based solvent. These will damage painted surfaces and melt plastic.